

## PROFESSIONAL TALK BACK INTERCOM OPERATION.

## A) From the master station.

- 1) To call an other station.
  - Select the desired station by dialling the corresponding number
    (See picture next). A ringing tone will be heard or the line will
    "splash open" immediately depending on the way of programming.
  - Start to communicate hands free. The speech direction is driven by the human voice.

## 2) To answer a call.

An incoming call will be announced by an acoustic tone and a red flashing LED showing the location of the calling station.

- Push the button "0" to accept the call and start to communicate hands free.

## B) From another station.

- If the station is provided with a full keypad, dial the desired number and operate further on the same way as the master station noted here above.





PRONOR N.V. Liefkensstraat 35A B-9032 GENT